



QTY	ITEM DESCIPTION
1	LEFT END PANEL
1	RIGHT END PANEL
3	CENTRE UPRIGHT
4	SCREEN FRAME
1	SEAT PLANK 4483 MM
1	SEAT BACKREST 4483 MM
QTY	BOLT KIT
16	M10 X 60 S/S BUTTON HEAD BOLT, & SPRING WASHER M10 X 38MM MUD GUARD WASHER
10	HEX HEAD METAL SEAT SCREWS
10	M10 X 150 MM CONCRETE SCREWS



ASSEMBLY INSTRUCTIONS:

THE SHELTER CONSISTS OF UPRIGHT SUPPORTS, SCREEN FRAMES AND BENCH SEATING PLANKS.

- 1. HOLD TWO UPRIGHT SO THE SCREEN WILL FIT BETWEEN THEM.
- 2. PLACE THE TWO LUGS ON THE BOTTOM OF THE SCREEN INTO THE LUGS ON EACH UPRIGHT.
- 3. ROTATE THE SCREEN UPWARD TILL IT FITS FLUSH WITH THE UPRIGHT.
- 4. INSERT TWO BOLTS, WASHERS AND SPRING WASHERS THROUGH THE SCREEN FRAME AND INTO THE UPRIGHTS. LOOSELY TIGHTEN TILL ALL SCREENS ARE IN PLACE.
- 5. AFTER THE SHELTER IS ASSEMBLED, ALIGN ALL THE UPRIGHTS USING THE SEAT AND BACKREST PLANKS.
- 6. REMOVE THE TAPE COVER FILM AND REINSTALL THE SEAT AND BACKREST.
- 7. THERE SHOULD BE NO GAPS BETWEEN THE FRAME PANELS. ONCE ALL FRAMES AND SCREEN ARE PROPERLY ALIGNED TOGETHER, TIGHTEN ALL THE BOLTS.
- 8. ADJUST THE POSITION OF THE SHELTER ON THE SLAB AND MARK THE HOLE POSITIONS ON THE SLAB.
- 9. DRILL 10MM X 100MM ANCHOR HOLES AND BOLT THE SHELTER IN PLACE USING 10MM X 150MM CONCRETE SCREWS.

