

NOTE FOR THE CUSTOMER:
SOME OF THE PARTS COME PRE-ASSEMBLED
BOLTS HAVE ALREADY BEEN ATTACHED TO THE ELBOWS.
PLEASE CHECK EVERY ITEM IS ACCOUNTED FOR, IF NOT CALL US IMMEDIATELY.

ASSEMBLY INSTRUCTIONS

- Lay the crossbar and two uprights on the ground.
- Insert the uprights into the crossbar and bolt together with M10 x 50mm s/s hex head bolts, washers and spring washers.
- Attach the net support arms with three M10 x 50mm s/s hex head bolts, washers and spring washers.
- Insert the side ground bars into the ends of the uprights. Secure with M10 x 50mm s/s hex head bolts, washers and spring washers.
- Insert the rear ground bar into the side ground rails and secure with M10 x 50mm s/s hex head bolts, washers and spring washers.
- Attach the net to the cross bar and uprights while they are lying on the ground by inserting the net edge into the profile, then pressing the PVC tube under the track curve.


PLACE SAND

REAR ELBOW


BAGS HERE

BAGS HERE

- Continue to attach the net by pressing the PVC tube under the track curve.
- Tie the net cord at the top rear of the net to the net rail pins to reduce sag in the net.



PLACEMENT OF NET INTO THE **BAR**







2 CROSS BAR (2774 MM)

- UPRIGHT (1687 MM)
- REAR GROUND BAR (2774 MM)
- GROUND SIDE BAR (1200 MM)
- CROSS BAR ELBOW
- REAR GROUND BAR ELBOW
- 4 UPRIGHT ELBOW
- LEFT NET SUPPORT ARM
- RIGHT NET SUPPORT ARM
- 8 MM PVC TUBE 7500 MM LONG

RIGHT END WHEEL ASSEMBLY

- LEFT END WHEEL ASSEMBLY
- 2 NET 3.0 X 2.0 X 0.8 X 1.5 M
- SAND BAGS
- M10 X 50 MM S/S HEX HEAD BOLT, WASHER & S/WASHER





ENGAGED POSITION



INTO THE SIDE GROUND

GALAXY 32f

Assembly Instruction



Oz Ring Pty Ltd Trading as:
Play Hard Sports Equipment ABN 79 066 094 559 24 Ern Harley Drive Burleigh Heads Qld 4220 Phone: (07) 5593 4494 Fax: (07) 5593 4338

Website: www.playhardsports.com.au Email: email@playhardsports.com.au