







ASSEMBLY INSTRUCTIONS TO ATTACH SHF FRAME OT THE EXTENSION ARM:

- 1. IDENTIFY THE SIDE OF THE SHF ADJUSTABLE BASKETBALL FRAME THAT CONNECTS TO THE OUTREACH ARM AND BACKBOARD
- THE SIDE CONNECTING TO THE OUTREACH ARM HAS AN "L"-SHAPED ANGLE STEEL AT THE TOP
- THE SIDE CONNECTING TO THE BACKBOARD HAS AN "I" SHAPED PIECE 1.2. OF FLAT STEEL AT THE TOP
- TWIST THE LOCKING PIN AND LOWER THE SHF FRAME TO IT'S LOWEST
- 3. CONNECT THE SHF FRAME TO THE OUTREACH ARM
- 3.1. PLACE THE "L" SHAPED ANGLE SECTION OVER THE EXTENDED "I" PIECE OF FLAT STEEL
- ALLOW THE SHF FRAME TO SWING DOWN SLOWLY 3.2.
- SECURE IN PLACE WITH 2 X 45 MM M10 HEX HEAD BOLTS, FLAT WASHER AND NYLOC NUT.
- 4. CONNECT THE SHF FRAME TO THE BACKBOARD
- 4.1. SLIDE THE BACKBOARD FRAME DOWN THE CENTER OF THE SHS FRAME SO THE ANGLE CATCHES ON THE OUTCROPPING FLAT STEEL
- SECURE THE BACKBOARD AND RING IN PLACE BY BOLTING WITH 4 X 125 MM M10 GAL HEX BOLTS, DOUBLE FLAT WASHER, SPRING WASHER AND NUT.

SN90r MULTIPLAY ROTATING BASKETBALL / NETBALL TOWER ASSEMBLY 3 OF 3

SN90r MULTIPLAY SYSTEM



Oz Ring Pty Ltd Trading as:

Play Hard Sports Equipment ABN 79 066 094 559 24 Ern Harley Drive Burleigh Heads Qld 4220 Phone: (07) 5593 4494

Fax: (07) 5593 4338 Website: www.playhardsports.com.au Email: email@playhardsports.com.au