

CROSS BAR

LEFT CROSS BAR ELBOW

LEFT UPRIGHT

GROUND LEVEL

-SPIGOT

BAR

PLACE THE GALAXY LABEL AND WEIGHT-

LABEL ON THE SIDE OF NET SUPPORT ARM

NET SUPPORT

PLACE SAFETY INSTRUCTIONS


AND WARNING LABEL, ONE-EACH ON OUTER SIDE OF THE

UPRIGHT BAR

UPRIGHT BAR

SPIGOT





ASSEMBLY INSTRUCTIONS

- 1. Lay the crossbar and two elbows on the ground, with the cavity facing upwards.
- 2. Insert the elbows into either side of cross bar and secure them with M10 x 50mm s/s hex head bolts, washers and spring washers.
- 3. Lay the uprights with spigot in line with the elbows with cavity facing upwards and secure them with M10 x 50 mm s/s hex head bolts, washers and spring washers.
- 4. Place the net support arm over the holes in the elbows and insert the M10 x 50mm s/s hex head bolts, washers and spring washers.
- 5. Attach the net to the cross bar and uprights while they are lying on the ground by inserting the net edge into the profile then pressing the PVC tube under the track curve
- 6. Stand the goal upright and place it into the ground sleeves
- 7. Tie the net cord to the net rail pins to reduce sag in the

GALAXY 32b SOCCER GOAL (without GROUND BARS)

WING NUMBER:

ASSEMBLY INSTRUCTIONS

ONE GOAL - 40 KG ONE NET - 1.4 KG

HALAT HARD

Oz Ring Pty Ltd
Trading as:
Play Hard Sports Equipment
ABN 79 066 094 559
13 Alex Fisher Drive
Burleigh Heads Qld 4220
Phone: (07) 5593 4494
Fax: (07) 5593 4338
Website: www.playhardsports.com.au
Email: email@playhardsports.com.au

This Drawing Remains the property of Play Hard Sports Equipment ©