





ALCATRAZ/BB
COMBINATION
FUTSAL/BASKETBALL



ALCATRAZ/BB
LAYOUT PLAN

ASSEMBLY AND INSTALLATION INSTRUCTIONS:

1. BORE DRILL 1 X 600 MM WIDE AND 1000 MM DEEP HOLE FOR F2 FOOTING AND 4 X 450 MM WIDE AND 600 MM DEEP HOLE FOR F1 FOOTING.
2. CONCRETE THE BASKETBALL POLE IN F2 FOOTING AND TWO FRONT AND TWO REAR UPRIGHT INTO THE GROUND.
ENSURE THE UPRIGHTS ARE CONCRETE IN CORRECT ORIENTATION AS SHOWN IN THE LAYOUT AND ARE AT CORRECT HEIGHT FROM THE PLAYING SURFACE.
3. LET THE CONCRETE TO SET FOR FEW DAYS BEFORE ATTACHING ANY OTHER PARTS.
4. THEN, ATTACH THE BASKETBALL EXTENSION ARM TO THE MAIN POLE USING M16 X 50 MM H.T. GAL HEX BOLT, DOUBLE FLAT WASHER & NUT.
5. ATTACH THE BACKBOARD TO THE EXTENSION ARM. THE BACK OF THE BACKBOARD FRAME HINGES ON TO OF THE ARM AND REST AGAINST THE BACKING PLATE.
6. THEN ATTACH THE RING AND FASTEN THE RING, BACKBOARD TO THE PLATE USING M10 X 90 MM GAL HEX BOLT, DOUBLE FLAT WASHER, SPRING WASHER & NUT.
7. ATTACH THE TWO SIDE AND TWO BACK PANEL TO THE UPRIGHTS USING M10 X 75 MM S/S HEX BOLT AND NYLOC NUT.
8. THEN, ATTACH THE CROSS BAR WITH TOP PANEL ON TOP OF THE ASSEMBLED FRAME.
 - USE M10 X 30 MM S/S HEX BOLT AND SPRING WASHER TO CONNET THE CROSS BAR TO THE UPRIGHTS
 - USE M10 X 120 MM S/S HEX BOLT AND NYLOC NUT TO JOIN TOP PANEL TO SIDE AND BACK PANEL

TITLE: ALCATRAZ/BB (ARIES)
COMBINATION FUTSAL &
BASKETBALL

DRAWING NUMBER:
ASSEMBLY DETAILS 2



Oz Ring Pty Ltd
Trading as:
Play Hard Sports Equipment
ABN 79 066 094 559
13 Alex Fisher Drive
Burleigh Heads Qld 4220
Phone: (07) 5593 4494
Fax: (07) 5593 4338
Website: www.playhardsports.com.au
Email: email@playhardsports.com.au